


AIR PRO 2500W OIL FILLED RADIATOR



AP0259 | AP0260 | AP0261

**PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE
USE & RETAIN THIS MANUAL FOR FUTURE REFERENCE.**

This product comes with a standard 1 year manufacturer warranty.

This can be extended up to 2 years by scanning below.



TECHNICAL DATA

Rated Power – 2500W

Rated Voltage – 220-240V

Rated Frequency – 50Hz

Model - YL-A18CT

Power Level 1 (Low Heat) – 1000W

Power Level 2 (Medium Heat) – 1500W

Power Level 3 (High Heat) – 2500W

Model identifier(s): AP0259 / AP0260 / AP0261					
Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input, for electric storage local space heaters only (select one)	
Nominal heat output	P_{nom}	2,5	kW	manual heat charge control, with integrated thermostat	☐ Yes ☒ No
Minimum heat output (indicative)	P_{min}	1,0	kW	manual heat charge control with room and/or outdoor temperature feedback	☐ Yes ☒ No
Maximum continuous heat output	$P_{max,c}$	2,5	kW	electronic heat charge control with room and/or outdoor temperature feedback	☐ Yes ☒ No
Power consumption				fan assisted heat output	☐ Yes ☒ No
In off mode	P_o	0,245	W	Type of heat output/room temperature control (select one)	
In standby mode	P_{sm}	-	W	single stage heat output and no room temperature control	☐ Yes ☒ No
In idle mode	P_{idle}	-	W	Two or more manual stages, no room temperature control	☐ Yes ☒ No
In network standby	P_{nom}	-	W	with mechanic thermostat room temperature control	☒ Yes ☐ No
Standby mode with display of information or status			☐ Yes ☒ No	with electronic room temperature control	☐ Yes ☒ No
Seasonal space heating energy efficiency in active mode	$\eta_{s,act}$	85,0	%	electronic room temperature control plus day timer	☐ Yes ☒ No
				electronic room temperature control plus week timer	☐ Yes ☒ No
				Other control options (multiple selections possible)	
				room temperature control, with presence detection	☐ Yes ☒ No
				room temperature control, with open window detection	☐ Yes ☒ No
				distance control option	☐ Yes ☒ No
				adaptive start control	☐ Yes ☒ No
				working time limitation	☐ Yes ☒ No
				black bulb sensor	☐ Yes ☒ No
				Self-learning functionality	☐ Yes ☒ No
				Control accuracy	☐ Yes ☒ No

SAFETY WARNINGS:

This product is only suitable for well insulated spaces and occasional use.



ATTENTION: This appliance has a thermal cut out switch.

If the appliance overheats, the thermal cut out will activate and shut down the appliance.

Should this occur, unplug from the mains and allow to cool for 30 minutes before re-use.



CAUTION: Do **NOT** immerse in water



CAUTION: Hot Surfaces



Do **NOT** cover



Do **NOT** use outdoors

1. This product is for household use **ONLY**.
2. Children should NOT play with this appliance
3. Cleaning and user maintenance should not be undertaken by children.
4. Children under the age of 3 should be kept well away from this appliance at all times, unless under constant supervision.
5. Extreme caution is necessary when any heater is used by or near children of any age and should only be done under strict supervision.
6. Children from ages 3-8 should only switch the appliance on/off only if it has been pre-placed / installed in its intended normal operating position and that they are supervised in doing so. Children within this age range should not plug in the appliance to the mains power, regulate or clean the appliance, or perform user maintenance.
7. This appliance can be used by children aged from 8 years and above, and for persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge if they have been given supervision or instruction concerning the use of this appliance in a safe way, and understand the hazards involved. This is recommended to occur under strict supervision also.


8. Ensure that the mains cable is fully extended before use, and arrange it so that it is not in contact with any part of the appliance
9. CAUTION – Some parts of this product can become very hot and cause burns. Particular attention needs to be given where children and vulnerable people are present. To avoid burns, do not let bare skin touch the hot surface.
10. If the product supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
11. In order to avoid overheating, do not cover the heater.
12. The heater must not be located immediately below a socket outlet.
13. Do not use this heater in the immediate surroundings of a bath, shower or swimming pool.
14. Do **NOT** pull on the power cord. Never move, carry or hang the appliance by the power cord.
15. WARNING: Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

16. This heater is filled with a precise quantity of special oil. Repairs requiring opening of the oil container are only to be made by the manufacturer, or their service agent who should be contacted if there is an oil leakage.
17. Regulations regarding the disposal of oil when scrapping the appliance at end of life should be followed.
18. Do **NOT** use this appliance to dry or heat clothes
19. Do **NOT** use this appliance in high humidity or steam-filled rooms
20. Avoid placing the power cord in areas where it can become a trip hazard.
21. Do **NOT** place the power cord under carpeting, or cover it with rugs, runners or similar items.
22. Do **NOT** use this heater if it has been dropped
23. Do **NOT** use this heater if there are visible signs of damage to the heater
24. Use this heater on a horizontal and stable surface, or fix it to the wall, as applicable.

25. **WARNING:** To reduce the risk of fire, keep textiles, curtains or any other flammable material a minimum distance of 1m away from the air outlet.
26. Do **NOT** attempt to repair, disassemble or modify the appliance. There are no user-serviceable parts inside.
27. **CAUTION:** It is not recommended to use this appliance with an extension lead where possible as they may overheat and cause a fire risk.
28. If using an extension lead, please ensure that you do not exceed the maximum rated running wattage / load of the extension lead and ensure to monitor the appliance carefully.
29. Disconnect from mains when not in use or when moving or cleaning.
30. Do **NOT** use this appliance with an external programmer, timer switch or any other device which would switch the appliance on automatically, unless this is pre-built into the appliance from the manufacturer.
31. Do **NOT** operate this appliance with wet hands.
32. Do **NOT** allow water, or other liquids to run into the interior of the appliance, as this could create a fire and/or electrical hazard.

- 33. Do **NOT** use this appliance while sleeping, or place it near a person who is sleeping.
- 34. Do **NOT** use this appliance near petrol, paints, flammable gases, ovens or other heating sources.


PRODUCT OVERVIEW





1. Front Handle
2. Radiator Fins
3. Adjustable Thermostat
4. Power Switch
5. Timer
6. Cable Holder
7. Wheels
8. Wheel Base (2x U Hooks & Wing Nuts Not Pictured)

ASSEMBLY


1. Turn the Radiator upside down on a scratch free and stable surface to prevent damage to the paint finish of the appliance, or your floor.



2. Fit the wheel assemblies onto the radiator by placing the U-Shaped bolts between the outermost fins on each side of the radiator (Fig. 2 -3).



3. Securely fasten the wheel assemblies onto the radiator by screwing the wing nuts onto the bolts (Fig. 4).



USAGE INSTRUCTIONS

1. Place the product in an upright position on a flat, steady, stable, heat-resistant surface. Make sure there are no flammable or heat sensitive items within 1 meter (40") of the appliance. Operating the appliance contrary to this could cause a hazard.

2. Turning the thermostat knob counter-clockwise to the minimum position (-) and setting the power switch to "0" for off. Then Insert the plug into a suitable wall outlet.

3. Turn the power switch from "0" to either "1" (Low Heat), "2" (Medium Heat) or "3" (High Heat).

4. Turn the thermostat knob clockwise to maximum position (+). When the room temperature rises to a comfortable level, slowly turn thermostat counter-clockwise until the indicator light just goes out.

To adjust the room temperature, turn the thermostat clockwise to raise the temperature, or counter-clockwise to lower it. Doing so will allow the heater to attempt keep the room temperature at the desired level.

5. To turn off the heater, set the power switch to the "0" position. Always unplug the radiator from the electrical outlet when it is left unattended or is not in use.


TIMER OVERVIEW

1 - CLOCK (24H)

2 - LIVE TIME ARROW

3 - TIMER SWITCH

4 - SEGMENTS



SETTING THE TIMER

NOTE: This is a 24h Timer.
There are in total 96 Segments.
Each segment represents a 15 minute interval.




Fig. 1

1. Firstly, turn the clock "1" clockwise to and align arrow "2" to match the current time.

2. Segments which are pushed outwards represent the time where the heater will be turned ON. Segments which are pushed inwards will represent the time where the heater will be turned OFF.

EXAMPLE: To set the radiator to turn on at 4pm and turn off at 5pm, push the 4 segments between 16 and 17 outwards (Fig 1).

3. Move the timer switch to the timer  symbol to enable the timer

(Fig 2).

4. If the timer switch is set at "I" position, the unit will work non-stop ignoring any timer setting. If the timer switch is set at "0" position, the unit will stay off ignoring any timer setting.




Fig. 2

NOTE 1: The timer setting will not reset itself when the unit has been switched off. However, any time that you unplug the unit, the clock will stop updating the live time, at next turn-on, the live time must be set again as indicated in point "1".

NOTE 2: When using the timer function, due consideration should be given to the fact that the heater may turn on whilst unattended.

SAFETY FEATURES

This Oil Filled Radiator is fitted with an overheat protection switch (thermal cut-out) which will power the appliance off automatically in case of overheating.

Should this occur, unplug the appliance and allow it to cool fully for at least 30 minutes.

Follow the operation instructions to restart the appliance after removing the source of the overheating (Poor Ventilation, item covering the radiator etc.)

The radiator should then function normally. In case the problem persists, please contact Air Pro Customer Support.

To avoid damage and to regulate temperature, this Oil Filled Radiator is also fitted a thermostatic safety device. The safety device will activate and cut out the power to the Radiator once a certain temperature is reached. The radiator will then start again automatically once the temperature has lowered.

This item is also fitted with an automatic tip-over cut off.

This will cut the power to the radiator if it is knocked over.

If this occurs, disconnect the item at the times to allow it to cool, before then attempting to move the radiator. Inspect the radiator for damage. If – the radiator is free from damage, plug back into the mains. The radiator should function as normal.

MAINTENANCE & DISPOSAL

CAUTION: Before Cleaning, switch off the radiator and disconnect it from the power socket, wait for the radiator to cool completely before cleaning.

Vacuum-clean the vents to remove dust and debris from these areas.

To remove dust on external surfaces, wipe the radiator with a damp (not wet) lint-free cloth, rinsed in hot soapy water only.

CAUTION: Do **NOT** use any harsh detergent or abrasive cleaners.

WARNING! Do **NOT** spray with liquids or submerge in any liquid or water.

WARNING! Do **NOT** attempt to clean the inside of the radiator.

Do **NOT** attempt to open the casing at any time. There are no user serviceable parts inside.

Where possible, please recycle this appliance at end of life. Check with your local authority for recycling advice and facility locations.



If further assistance is required, or you face difficulty when using this device, please contact our support team by emailing support@airprohome.com

You can also contact us by scanning the QR Code below



